

NADCA Vacuum Test Collection – Field Technician Guide

1. Gather Required Materials

- Pre-weighed filter cartridge.
 - NADCA-compliant vacuum pump vacuum tubing
 - Template and tape
 - Field log sheet
-

2. Select the Sampling Location

- Choose a representative area of ductwork (e.g., main trunk line after cleaning).
 - Ensure airflow is off and access is safe.
 - Choose a flat, accessible surface inside cleaned ductwork.
 - Location should represent average condition of system (not worst or best).
-

3. Set Up the Vacuum System and Template

- Tape the template directly to the sample area.
 - Insert the filter cassette into the vacuum line.
 - Turn on the vacuum pump and ensure that airflow is drawing through the cassette.
 - Ensure the pump is set to 10 l/m flow rate.
-

4. Vacuum the Template Area

- Slowly and evenly vacuum within the boundaries of the template.
 - Keep the nozzle no more than 1 inch from the surface.
 - Do not touch the cassette to the surface of the template.
 - Make multiple passes to ensure all loose debris is collected.
 - Do not vacuum outside the template.
 - Time the collection of the sample, the pump must run for 5.7 minutes.
-

5. Remove and Seal the Sample

- Carefully remove the filter cassette without shaking or touching the intake side.
- Store the sample in a clean, sealed bag or container.
- Deliver to lab for pre/post weight analysis.

NADCA Vacuum Test Collection – Field Log Sheet

Date: _____

Project Name: _____

Technician Name: _____

Results Contact: Phone: _____

Email: _____

Sample information:

- ☐ Pump calibrated to 1 LPM flow rate
- ☐ Clean powder free gloves worn when handling filter
- ☐ Pump run for 5.7 minutes during collection
- ☐ Stoppers reattached to filter after collecting the sample

Cassette Num	
Location	
Time	